









Mittelwerttemperatur-Messumformer
Transmetteur de la valeur moyenne de température
Averaging Temperature Transmitter
Trasmittitore del valore medio della temperatura
Transmisor del valor medio de la temperatura
Medelvärld Temperatur-Mätomformare
Gemiddelde waarde Temperatuur-Meetopnemer

MV 23211

Montageanleitung
Instruction de montage
Installation instructions
Istruzioni di montaggio
Instrucciones de montaje
Monteringsanvisning
Montagevoorschrift

**TMUP
210, 220**





- Änderungen vorbehalten. - Nous nous réservons le droit d'apporter, sans avis préalable, toutes modifications que nous jugerons nécessaires au matériel décrit. - Right of amendment reserved. - Con riserva di modifiche. - Sujeto a posibles modificaciones. - Aendringar vorbehalten. - Veranderingen voorbehouden.