






KTM 512-32 FC20





1



2



3



4




KTM 512-32 FC20

Position - Einstellung

	0,0	1,0	2,0	3,0	4,0	5,0	6,0
,0	12	580	1474	2689	3493	4047	4341
,1	69	669	1596	2769	3548	4076	4352
,2	126	759	1717	2850	3604	4106	4364
,3	182	848	1839	2930	3659	4135	4375
,4	239	938	1960	3011	3715	4165	4386
,5	296	1027	2082	3091	3770	4194	4398
,6	353	1116	2203	3171	3825	4223	4409
,7	410	1206	2325	3252	3881	4253	4420
,8	466	1295	2446	3332	3936	4282	4431
,9	523	1385	2568	3413	3992	4312	4443

Flow - Volumenstrom (l/h)

5



6